

# DORMER PRAMET



# BORRSATSER TILL SPECIALPRIS

Dormer standardborr i High Tech-kvalitet med TiN-beläggning



**389**  
SEK

**1248**  
SEK



**808**  
SEK

**Borrsats** A099DRILLBOY

Innehåll: 43 st A002-borror  
Borrdiameter från 3.0 till 13.0 med 0.5 mm stigning + gängdim.; 3.3 - 4.2 - 5.0 - 6.8 - 8.5 - 10.2 - 12.0 mm.

HSS DIN 338 4XD 118° TN N

■	1.1	1.2	1.3	1.4	3.1	3.2	7.1	7.2	8.1	8.2					
■	1.5	1.6	2.1	2.2	2.3	3.3	3.4	4.1	4.2	4.3	5.1	5.2	5.3	6.1	6.2
■	6.3	6.4	7.3	7.4	8.3	9.1									

**Borrsatser** A095201 & A095204

A095201 Sats med 19 st A002-borror, 1-10 mm x 0,5 mm  
A095204 Sats med 25 st A002-borror, 1-13 mm x 0,5 mm

HSS DIN 338 4XD 118° TN N

■	1.1	1.2	1.3	1.4	3.1	3.2	7.1	7.2	8.1	8.2					
■	1.5	1.6	2.1	2.2	2.3	3.3	3.4	4.1	4.2	4.3	5.1	5.2	5.3	6.1	6.2
■	6.3	6.4	7.3	7.4	8.3	9.1									

Priserna gäller t.o.m. 31/12-2020

# DORMER PRAMET



# FÖRSÄNKARE TILL SPECIALPRIS

Dormer försänkarsatser - blanka och belagda



**G2361**

815:-

**G2363**

1151:-



**G2364**

897:-

**G2365**

1266:-

## Försänkarsatser

**G2361** Sats med 6 st försänkare G136  
Diam: 6.3, 8.3, 10.4, 12.4, 16.5, 20.5

HSS		DIN 335C			90°										
■	1.1	1.2	1.3	1.4	4.1	4.2	5.1	5.2	6.1	6.2	6.3	7.1	7.2	8.1	
■	1.5	1.6	2.1	2.2	2.3	3.1	3.2	3.3	3.4	4.3	5.3	6.4	7.3	7.4	8.2

**G2363** Sats med 6 st försänkare G560 (Belagd)  
Diam: 6.3, 8.3, 10.4, 12.4, 16.5, 20.5

HSS		TiN	DIN 335C			90°									
■	1.1	1.2	1.3	1.4	1.5	2.1	3.1	3.2	3.3	3.4	5.1	5.2	5.3	7.3	7.4
■	1.6	2.2	2.3	4.1	4.2	4.3	6.1	6.2	6.3	6.4	7.1	7.2	8.1	8.2	

**G2364** Sats med 6 st försänkare G106  
Diam: 6.3, 8.3, 10.4, 12.4, 16.5, 20.5

HSS		DIN 335C			90°										
■	1.1	1.2	1.3	1.4	1.5	4.1	4.2	4.3	5.1	5.2	5.3	6.1	6.2	6.3	
■	1.6	2.1	2.2	2.3	3.1	3.2	3.3	3.4	6.4	7.1	7.2	7.3	7.4	8.1	8.2

**G2365** Sats med 6 st försänkare G506 (Belagd)  
Diam: 6.3, 8.3, 10.4, 12.4, 16.5, 20.5

HSS		TiN	DIN 335C			90°									
■	1.1	1.2	1.3	3.1	3.2	3.3	3.4	7.1	7.2	7.3	7.4				
■	1.4	1.5	1.6	4.1	4.2	4.3	5.1	5.2	5.3	6.1	6.2	6.3	6.4	8.1	8.2

Priserna gäller t.o.m. 31/12-2020.